



VIEW OF THE LEFT COLUMN OF THE STEEL SUPPORT STRUCTURE ON WHICH THE DISCONNECTOR TYPE 403.11 ALONG WITH ITS EARTHING SWITCH AND THEIR RESPECTIVE OPERATING MECHANISMS SHALL BE INSTALLED ON




VIEW OF THE RIGHT COLUMN OF THE STEEL SUPPORT STRUCTURE ON WHICH THE DISCONNECTOR TYPE 403.11 SHALL BE INSTALLED ON

**DETAIL B**  
Metal plate for the mounting of the operating mechanism of the disconnecter and the operating mechanism of the earthing switch



**CROSS SECTION A-A**



- NOTES**
1. All dimensions shown are mandatory.
  2. All dimensions are in millimetres (mm).

**DRAWING NO. 403.11/1**  
Drawing indicating the steel support structure on which the disconnecter type 403.11 along with its earthing switch and their respective operating mechanisms shall be installed on.